

Marvelmind Indoor Navigation System

Operating manual

v2019_02_05

www.marvelmind.com

Table of contents

1. Version changes.....	4
2. Executive summary	7
3. Basics of the system	9
3.1 What's in the box.....	9
3.2 Indoor Navigation System architecture	10
3.3 Indoor "GPS" System close-up and internal view.....	11
4. System elements.....	14
4.1 Stationary beacon	14
4.2 Mobile beacon a.k.a. "hedgehog"	15
4.3 Modem/router	16
4.4 Different types of beacons	17
1) HW v4.9 beacon.....	17
2) DSP beacon	18
3) Mini-beacon.....	19
4) Beacon-TX-25-IMU-IP67-RS485	20
5) Beacon-DSP-RX-IMU-IP67-RS485	21
4.5 Beacons comparison	22
5. Setting up the system (Non-Inverse Architecture).....	23
5.1 Ultrasonic coverage.....	23
5.2 Charging beacons and other details	24
5.3 DIP switch modes.....	25
5.4 First setup of your device	26
5.5 HEX programming.....	27
5.6 DFU Programming	28
5.7 Setup the Dashboard SW	31
6. Setting up the system (Inverse Architecture)	35
6.1 How to launch Inverse system.....	35
7. Dashboard menu and parameters	37
7.1 Dashboard general view.....	37
7.2 Table of distances	38
7.3 Devices list	40
7.4 Visualization settings.....	41
7.5 Map settings.....	42
7.6 Modem/beacon's quick control panel.....	43
7.7 Modem's settings	44
7.8 CEILING and MIRRORING buttons on the Dashboard	65
7.9 Radio frequency band and Carrier frequency	66
7.10 Different hedgehog colors in the Dashboard.....	67
8. SW feature/settings descriptions	68
8.1 Licenses	68

8.2	Floors feature (FN0011)	70
8.3	Submap's settings	73
8.4	Axis rotation feature (FN0002).....	74
8.5	Vertical submaps feature (FN0003)	76
8.6	Handover zones setting	79
8.7	Submaps feature (FN0004)	80
8.8	Paired beacons (FN0005)	87
8.9	Map settings	88
8.10	Hedge color change (FN0006)	89
8.11	Payload streaming (FN0007).....	91
8.12	IMU feature (FN0008).....	92
8.13	IMU axis positioning	94
8.14	Player feature (FN0009)	95
8.15	Real-time player feature (FN0010)	98
8.16	CSV format.....	100
9.	Interfaces	101
9.1	Beacon HW v4.9 external interface 4x4 pinout top view	102
9.2	Modem HW v4.9 external interface pinout top view	103
10.	Advanced system settings and optimization	104
10.1	How to place beacons	105
10.2	Using Oscilloscope.....	106
10.3	Proper ultrasonic signal detection	107
10.4	Using hedgehog.log file	108
10.5	System accuracy evaluation	109
10.6	Calibration of the accelerometer	110
10.7	Title reserved	112
10.8	Settings to obtain correct north direction	113
10.9	Communication of Pixhawk with Marvelmind mobile beacon	114
10.10	Sending path to robot	115
10.11	Proper ultrasonic coverage.....	117
10.12	Sensors settings: example for 2D and mobile beacon	119
10.13	Powering beacons	120
11.	Frequently Asked Questions.....	121
12.	Troubleshooting check-list.....	123
13.	Contacts	125

1. Version changes

V2018_02_05

- Licenses described
- Minor fixes and improvements

V2018_01_29

- DSP Inverse SW flashing described
- Added new types of beacons
- Minor fixes and improvements

V2018_01_12

- DSP beacon and Mini-beacon described
- IMU axis described
- Minor fixes and improvements

V2018_12_02

- Major new feature – support for 255 beacons and 255 submaps per modem
- New feature: user must setup handover zones between submaps to guarantee handover quality for complex maps with multi-floor and similar
- New feature: default wireless connection is setting is now 153kbps (used to be 38kbps). Radio profile 153kbps provides radio coverage range nearly as much as 38kbps and update rate nearly as high 500kbps, i.e. it is a middle of 38kbps and 500kbps, combining the best of both
- Correction: USB streaming in power save mode improved
- Correction: Zero IMU button in the Dashboard is improved, while button Reset IMU is removed completely
- Correction: ultrasound TX is not reset to 31kHz when Default button is pressed. Now, several types of ultrasonic frequencies supported, so 31kHz is not anymore a default ultrasonic frequency for all beacons
- Improved: both energy saving and tracking quality with Power Saving mode enabled
- Improved: only beacons with selected tick in the Dashboard lower menu will be accepted to the network – not any addresses. This improves predictability of the network, when there many beacons that may not belong to the network. Their attempts to join the network will be blocked
- Improved: now, submaps support up to 4 beacons only. More than that – build another submap. Up to 255 beacons and up to 255 submaps are supported per beacon
- Bug fix: improved map building with active hedgehog
- Bug fix: duplicated address might work incorrectly in some cases

V2018_11_08

- Real-time player feature described

V2018_08_30

- New SW features described
- New Dashboard view described

V2018_08_03

- Calibration of accelerometer described
- F.A.Q. updated
- Troubleshooting guide described
- Refreshed links
- Player feature described
- IMU feature described
- Minor fixes

V2017_12_29

- SW features paragraph updates
- General updates
- Sending path to robot
- Radio frequency band switch in latest Dashboard version
- Sending path to robot
- Paired beacons feature described
- Submap feature help video
- Different hedgehog colors in the Dashboard
- FAQ updates

V2017_11_01

- Added Sensors settings
- Added Dashboard features
- FAQ
- Fresh Dashboard screenshots
- General updates

V2017_09_08

- Added estimation of accuracy of distances measurement
- Added Raw inertial sensors data
- Added Communication of Pixhawk with Marvelmind mobile beacon
- Added Optimal settings for stationary beacons in small and big rooms
- Added Optimal settings for noisy environment

V2017_07_20

- Cleaned up description and some corrections were added
- Description of HW v4.5 removed from this manual and given in the previous version of the manual, which can be found here: http://www.marvelmind.com/pics/marvelmind_navigation_system_manual_HW_v4.5.pdf
- Description of HW v4.9 added
- Introduced plastic housing for beacons and modem
- Introduced 915MHz variant for the US market (HW v4.9 only)
- General updates and description improvements
- Submaps described

- HEX and DFU firmware general updates + new links
- Obtaining raw data from inertial sensors
- Settings to get correction north direction

2. Executive summary

Marvelmind Indoor Navigation System is an off-the-shelf indoor navigation system, designed to provide precise ($\pm 2\text{cm}$) location data to autonomous robots, vehicles (AGV), and copters. It can also be used to track moving objects via mobile beacons attached to them. Other applications include, for example, forklifts, virtual reality (VR) systems, helmets for construction workers or miners, etc.

The navigation system consists of a network of stationary ultrasonic beacons interconnected via radio interface in a license-free band, one or more mobile beacons installed on objects to be tracked and modem providing gateway to the system from PC or other computers.

Mobile beacon's location is calculated based on a propagation delay of an ultrasonic pulses (Time-Of-Flight or TOF) between stationary and mobile beacons using trilateration algorithm.

The system can build the map of stationary beacons automatically (For Non-Inverse Architecture). In simple cases, no additional manual data input or any manual distance measurements are required. This map formed once can be frozen and stored in modem's memory and the system becomes fully active within 7 to 10 seconds after the modem is powered.



Fig. 1: Example of starter set based on HW v4.9

Minimum configuration requirements (Non-Inverse Architecture) to ensure optimal performance of the Marvelmind Indoor Navigation System:

- For 3D (X, Y, Z) tracking: an unobstructed line of sight (hearing) between a mobile beacon and 3 or more stationary beacons within 30 meters
- For 2D (X, Y) tracking - an unobstructed line of sight (hearing) between a mobile beacon and 2 or more stationary beacons within 30 meters

Key capabilities:

Parameter	Technical Specifications
Distance between beacons	<ul style="list-style-type: none"> - Reaches up to 50 meters in lab conditions (DSP beacon to HW v4.9 with RX4 only) - Recommended distance is 30 meters (Transducer4 on the first beacon is looking straight at the Transducer4 on the second beacon, other transducers are switched off)
Coverage area	<ul style="list-style-type: none"> - Reaches up to 1000 m² with the Starter Set configurations - Coverage for larger territories is provided using submap – similar to cells in cellular networks
Location precision	<ul style="list-style-type: none"> - Absolute: 1–3% of the distance to the beacons - Differential precision: ±2 cm
Location update rate	<ul style="list-style-type: none"> - 1/20Hz to 25Hz (Ultrasonic based only) - 100Hz with ultrasonic + IMU fusion enabled - Can be set manually via Dashboard software - Depends on the distance between mobile and stationary beacons (shorter distance—higher update rate) - Depends on the number of mobile beacons (Non-Inverse Architecture; for Inverse Architecture no such dependency) - Depends on the radio profile (500kbps vs. 38kbps) - Slightly depends on the number of stationary beacons—dependence is not the same as for mobile beacons
Power supply	Internal: 1000mAh LiPo battery (HW v4.9) <ul style="list-style-type: none"> - Battery lifetime: from 2 days to several months depending on the mode of operations *For other types of beacons look to the comparison table
	External: micro USB – recommended for permanent use
Weight	Mobile beacon (HW v4.9) from the starter set: <ul style="list-style-type: none"> - 59 grams (including 1000mAh battery, HW v4.9 housing and 50mm antenna) - 27 grams (HW v4.9, bare board w/o battery) *For other types of beacons look to the comparison table
Beacon size	Size: 55x55x33 mm (with 50mm antenna: 55x55x65mm) (HW v4.9) *For other types of beacons look to the comparison table

3. Basics of the system

3.1 What's in the box

3.1.1. [HW v4.9 Starter Set](#):

- 4 x Stationary beacons (HW v4.9)
 - 1 x Mobile beacon (HW v4.9) (aka "hedgehog")
 - 1 x Modem/Router

* Starter set includes beacons without IMU. All pictures shown are for illustration purposes only. Actual product may vary due to product enhancement. Characteristics are the same or better unless stated otherwise.



3.1.2. [DSP Starter Set](#):

- 4 x DSP beacons (HW5.0x)
 - 1 x Mobile beacon (HW v4.9) + IMU (aka "hedgehog")
 - 1 x Modem/Router




*This is just an example of two starter sets.
More options you can see on our site: [Products](#)

3.2 Indoor Navigation System architecture


Marvelmind Indoor Navigation System provides high-precision ($\pm 2\text{cm}$) indoor coordinates for autonomous robots and systems ("indoor GPS"). A brief description of the key elements of the system is given on the scheme below.

There you can see two different types of architectures described:

Non-Inverse Architecture



Inverse Architecture



Here you can see the differences between architectures: [Architectures comparison](#)

3.3 Indoor “GPS” System close-up and internal view

Here, you can see how system elements actually look like

- HW v4.9 beacon (without housing)



- HW v4.9 modem (without housing)



- DSP beacon (HW5.05)



- Mini-beacon (HW5.07)



- HW v4.9 beacon with Mini-beacon size comparison



- HW Beacon-DSP-RX-IMU-IP67-RS485



- Beacon-TX-25-IMU-IP67-RS485



4. System elements

4.1 Stationary beacon

- Usually, mounted on the walls or ceilings above the robot with ultrasonic sensors facing down—to provide the most robust unobstructed ultrasonic signal coverage to the robot. However, for automatic landing and indoor navigation of copters, for example, it is recommended to install mobile beacon horizontally on the belly of the copter so that the beacon would be looking downwards
- The position and orientation of the beacons should be chosen in a way that provides maximum ultrasonic signal coverage. System efficacy strongly depends on the quality of ultrasonic signal received by stationary beacons
- Stationary beacons emit and receive ultrasound during the map configuration period. Once the map is formed and frozen, they only work as the receivers
- Stationary beacons have no exterior differences with regard to mobile beacons
- Inertial measurement unit (IMU) is not installed on the stationary beacons
- The mobile and stationary beacons can be easily interchanged by selecting corresponding [option](#) (except for IMU) during configuration in the Dashboard
- There are 433MHz and 915MHz versions available. A proprietary radio protocol is used for communication and synchronization. Other ISM bands are available upon request as well
- Stationary beacon can be equipped with full-size 165mm antenna (for 433 MHz), which provides more robust radio connection between modem and beacons (for HW v4.9)



Fig.2: HW v4.9 as an example

4.2 Mobile beacon a.k.a. “hedgehog”

- The mobile and stationary beacons can be easily interchanged by selecting the [option](#) in the Dashboard
- The mobile beacons designed to be placed on a robotic vehicle, copter/drone, AGV, or helmet to trace its location. Formally speaking, location of the mobile beacon is traced—not the robot itself. Since the sizes and the location of the central point of the mobile beacon and the robot are different, the difference taken into account in the robot’s software (SW)
- It is recommended to place the mobile beacon horizontally to provide optimal ultrasonic coverage in the upper hemisphere
- Its sensors must not be covered with anything that can reduce the strength of ultrasonic signal. For example, the system won’t normally work, if one puts the mobile beacon in a plastic box
- The beacon’s coordinates are updated according to the rate set on the Dashboard
- The system may contain one or several mobile beacons. Current implementation relies on a time-division multiple access approach. Thus, if two mobile beacons are activated, they share the same system bandwidth. It means that, if the 16 Hz update rate is selected in the Dashboard and there are 2 mobile beacons in the system, each beacon’s location will be updated with the rate of $16\text{Hz}/2 \sim 8\text{Hz}$. If there are 3 mobile beacons $\Rightarrow 16\text{Hz}/3 \sim 5\text{Hz}$, etc. Future SW implementation may contain different solution that will improve update rates in setups with multiple mobile beacons
- Location data is obtained either from the “hedgehog” via USB (virtual UART), UART, SPI, or from the modem/router via USB (virtual UART). More information on interfaces can be found [here](#) (DSP beacon do not have pinouts, only over micro-USB)
- Data from the beacon sent in a streaming format identical to that of GPS (NMEA 0183)
- There are 433MHz and 915MHz (915/868MHz only for DSP beacon) versions available. Proprietary radio protocol is used for communication and synchronization
- The “hedgehog” has been successfully integrated with Windows PC, Linux machines, Raspberry Pi, Arduino boards, Intel boards, etc.



Fig.2: HW v4.9 as an example

4.3 Modem/router

- Modem is the central controller of the system. It must be powered at all time when the Navigation System is working. It recommended to use an active USB hub for that purpose or even a regular cellular phone USB power supply. A USB power bank can also be used
- The modem is also used to set up the system, monitor it, and interact with the Dashboard
- It can be placed anywhere within radio coverage for permanent radio connection with all beacons—usually in the radius of up to 100 meters with antennas from the Starter Set.
- Radio coverage further extended to a few hundred meters by using a lower bitrate of 38kbps and full-size (165mm for a 433MHz band) antennas, which have been tested to provide up to 400 m in ideal conditions
- There are 433MHz and 915MHz versions available
- A proprietary radio protocol used for communication and synchronization between modem and beacons



Fig.3: HW v4.9 as an example

4.4 Different types of beacons

1) HW v4.9 beacon

HW v4.9 beacon can be used in both the Non-Inverse Architecture (NIA) and in the Inverse Architecture (IA): [NIA and IA comparison](#)



2) DSP beacon

The DSP Beacon can be used in both the Non-Inverse Architecture (NIA) and in the Inverse Architecture (IA): [NIA and IA comparison](#)

The DSP beacon HW 5.xx differs from regular Beacon HW v4.9 in several ways:



- It is an RX-only beacon, i.e. it can receive, but it cannot transmit ultrasonic signal
- The fact that it is RX-only makes it far more sensitive, i.e. you will get a longer range between Beacon HW v4.9 and DSP v5.xx than between Beacon HW v4.9 and Beacon HW v4.9
- DSP beacon can receive any ultrasonic frequency from the bands: 19kHz, 25kHz, 31kHz, 37kHz, 45kHz, 56kHz. The filter can be simply selected in the Dashboard. At the same time, the working ultrasonic frequency of Beacon HW v4.9 is HW-defined by ultrasonic sensors and can't be changed
- DSP beacon can receive several ultrasonic frequencies at once. That is used in Inverse Architecture. See the comparison
- The DSP Beacon is significantly smaller, than Beacon HW v4.9
- The DSP Beacon can work with regular Beacons HW v4.9 in any combination as a part of a Starter Set or as a part of navigation systems and it is a superior RX-only replacement to HW v4.9. At the same time, since it is RX-only beacon, the Beacons HW v4.9 are here to stay as universal dual-use beacons
- The product which is smaller than a regular beacon
- Can play a role of stationary beacon
- Can play a role of mobile beacon (in inverse system)
- Has digital microphone, which is more sensitive than regular sensors
- Can't emit ultrasound
- Light weighted
- Can be water-protected
- The component of the [Marvelmind Helmet](#) and [Marvelmind Watch](#)

3) Mini-beacon

The Mini-beacon is an TX only beacon, i.e. it can transmit, but cannot receive ultrasound

Comparison to Beacon HW v4.9:

- Smaller size and lighter: 47x42x15mm & 25g vs. 55x55x33mm & 62g (or 55x55x64mm with antenna)
- TX only, i.e. Mini-beacon can only transmit ultrasonic and cannot receive. Beacon HW v4.9 is dual-use: can receive and transmit ultrasonic
- Battery – 250mAh vs. 1000mAh in a regular beacon. But Mini-beacon has a new more efficient ultrasonic TX module, thus, battery lifetime in TX mode is even superior to the Beacon HW v4.9
- Tested battery lifetime with 8Hz – 96h. With lower update rate – nearly proportionally longer. Very efficient ultrasonic TX module
- Mini-beacon has only USB (virtual UART) output – no additional pins
- Mini-beacons always have embedded IMU – newer and better, but it has 3D accelerometer and 3D gyroscope, but no magnetometer (which we do not recommend to use indoor anyway, due to magnetic field distortion indoor)
- Embedded antenna – smaller size, but smaller radio coverage ~50m with regular Modem HW v4.9 as compared with ~100m of Beacon HW v4.9 with Modem HW v4.9
- Range in ultrasonic is virtually on par with regular Beacon HW v4.9 – up to 30m with Beacon HW v4.9 as RX beacon. At the same time, for example, a combination of DSP RX beacon + Mini-beacon TX provide a better coverage and a stronger signal, than Beacon HW v4.9 + Beacon HW v4.9
- This HW is for the 915MHz band (US band) only, i.e. 433MHz (EU band) is not supported and not planned. Future HW versions will support another ISM band for the EU – 868MHz. With further limitation of radio coverage, this HW (the 915MHz version) can be used for the 868MHz band already now



4) Beacon-TX-25-IMU-IP67-RS485

Heavy outdoor beacon:

- TX-only beacon – can transmit ultrasonic, but can't receive it
- Electronics is IP67 protected
- Special IP67-protected 25-kHz transducers
- External antenna with SMA connector for extended radio range
- Two IP67 external connectors
- Corresponding IP67 connectors (male part) included
- No battery inside
- Extended working temperature range: -40C...+50C (not tested, provided by design)
- Embedded reset switch and DFU switch – magnetic control
- Can work together with modems with corresponding radio (radio bands must match)
- Can work with any DSP beacon or Beacon HW v4.9 with 25kHz ultrasonic sensors (radio bands must match)
- Most of all designed to work together with Outdoor versions of DSP beacons: DSP “watch” HW v5.xx and heavy outdoor Beacon-RX-IP67 (radio bands must match)
- Up to 30m with Beacon DSP+IMU+Outdoor
- Optional external IP67 converter ~110/220V to +12V

*Produced on request. Lead time – several days.



5) Beacon-DSP-RX-IMU-IP67-RS485

Heavy outdoor beacon:

- RX-only beacon – can receive ultrasonic, but can't transmit it
- Electronics is IP67 protected
- Special IP67-membrane for ultrasonic sensor
- External antenna with SMA connector for extended radio range
- Two IP67 external connectors
- Corresponding IP67 connectors (male part) included
- No battery inside by default – external power bank or external power supply (+12V Or +5V). But, optional variant with internal battery is possible
- Extended working temperature range: -40C...+50C (not tested, provided by design) – only for the variant without battery
- Embedded reset switch and DFU switch – magnetic control
- Can work together with modems with corresponding radio (radio bands must match)
- Supports wide range of ultrasonic frequencies: 19/25/31/37/45/56 kHz
- Most of all designed to work together with heavy-outdoor version Beacon-TX-25-IMU-IP67-RS485 – up to 30m range in ultrasonic
- Range in radio – up to a few hundred meters in open space with full-size antennas
- Optional external IP67 converter ~110/220V to +12V

*Produced on request. Lead time – several days



4.5 Beacons comparison


Here you can see the differences between different types of beacons:

https://marvelmind.com/pics/!_Marvelmind_Precise_Indoor_GPS_beacons_comparison.pdf

5. Setting up the system (Non-Inverse Architecture)

5.1 Ultrasonic coverage

Each transducer on the beacons has $\sim 90^\circ$ of ultrasonic coverage



5.2 Charging beacons and other details

- The Beacon has 5 sensors (transducers): RX1, RX2, RX3, RX4, and RX5
- Charging occurs automatically every time a USB charger is attached to the board. LED 1 is active and lights red
- It takes 1–2 hours to fully charge the board's battery
- If you plan to use a charger for permanent powering of the beacon, make sure that the power source is not noisy (The USB +5V is not noisy). The performance can be monitored by using:



Dashboard => View => Oscilloscope.


Read the paragraph [Using Oscilloscope](#)

- When the board is charged and turned on, LED 2 will blink every few seconds, if to press RESET button and modem is active. If modem is not active or works on a different radio channel, the beacon automatically goes into sleep mode after 1 minute.


5.3 DIP switch modes

Examples below are given for HW v4.9, which can be slightly different for other types of beacons.


- 1) **Power = OFF, DFU = OFF**: Charging is possible; beacon disconnected from internal battery. This mode recommended, if you want to keep the battery fully charged for a long time and to store the beacon on the shelf



- 2) **Power = ON, DFU = OFF (pictured below)**: Normal working mode for the beacon. The beacon is fully powered and will wake up every a few seconds to monitor radio signals from the modem. Power consumption is still minimal, if the beacon sleeps; the battery can last for many weeks or months. It is recommended the beacon be kept in this mode and the DIP switch not be touched at all, unless you plan to store the beacon on the shelf. If that's the case, then mode 1 is recommended



- 3) **Power = ON, DFU = ON**: DFU programming mode. It is used for the initial SW uploading or when the HEX SW cannot be uploaded from the Dashboard



5.4 First setup of your device

All the examples are given for HW v4.9, which can be slightly different for other types of beacons. But all the basic steps are the same. Check the [comparison slide](#) is necessary.


The steps below describe the very first time you set up of the system:

- Unpack the system. Watch the help video: https://youtu.be/sOce7B2_6Sk
- Check that your boards are charged; see that all switches on the beacons are in the correct position (**Power = ON**; **DFU = OFF**). See the paragraph [DIP switch modes](#)
- Press the **RESET** button on each beacon. If LED 2 is not blinking, it means your board is turned off or discharged. Check the position of the DIP switch again or charge the beacon via USB

5.5 HEX programming

Examples below are given for HW v4.9, which can be slightly different for other types of beacons.

- After charging boards, download the latest stable SW package from https://marvelmind.com/pics/marvelmind_SW.zip
- Run the Dashboard and update the SW for all beacons and modem using **Dashboard => Firmware => Choose the file => Program**



- If you see the message “**Not found modem connection to computer through USB**” in the Dashboard or your PC does not recognize beacons/modem, it usually means that the STM32 driver is not installed. To install the driver, download it with link at top window in the Dashboard and run the installation file, then click on the link under and install the driver

Ensure that:

- (a) You are programming the modem's SW to the modem and the beacon's SW to the beacon
- (b) You are using SW for 4.9, if you have HW v4.9; and you have the SW from the same SW pack, i.e., the Dashboard SW, modem SW, and beacon SW must be from the same SW pack. Don't mix SW releases

5.6 DFU Programming

Examples below are given for HW v4.9, which can be slightly different for other types of beacons.


DFU programming or SW uploading is used when HEX SW uploading in the Dashboard cannot be used. For example, when you are updating from a very old SW version or when the SW includes major changes to the system and the only possible way to update the SW is via DFU programming

- After the DFU SW upgrade, futures SW upgrades can be done in a regular manner via the Dashboard
- To start programming, move the beacon's DIP switch to the DFU programming mode, as described in the paragraph on [DIP switch modes](#)
- Download the latest [SW package](#), unzip it, and select the proper version of the SW for your HW and for your frequency variant. Remember that for DFU programming, you should use DFU SW (DfuSe), not Dashboard's .hex file
- Download DfuSe
- Here you will find different versions of DfuSe. v3.0.4 or v3.0.5, whichever works the best for your Windows: [DfuSe v3.0.4](#) or [DfuSe v.3.0.5](#)

DFU Programming:


- Put DIP switch into **Power = ON, DFU = ON**
- Connect the beacon via USB to your PC
- Run DfuSe
- Press the **RESET** button on your beacon
- In the upper left corner of the DfuSe program, you will see a device connected in the DFU mode

- Choose the DFU driver (file) for the beacon



- Click the **UPGRADE** button
- After a couple of seconds, the DFU will be uploaded to the beacon. Make sure it actually takes 1–3 seconds and does not happen immediately. Otherwise, the SW has not been really uploaded. If the DFU appears to upload immediately, check the "Choose" button you used or change the version of DfuSe SW you selected
- Move the DIP switch into **Power = ON, DFU = OFF**
- Start the Dashboard and press the **RESET** button on the beacon
- Check SW on the beacon afterwards
- Everything should be OK with SW now. DFU programming is complete
- Follow the same scenario for the modem:
 - Here is the [link](#) for the modem DFU programming. The steps are similar to those for beacon DFU programming
 - After uploading DFU driver by DfuSe short circuit holes temporarily as shown on the picture (for v4.9) press **UPGRADE** button in the DfuSe program
 - After a couple of seconds, the DFU will be uploaded to the modem. Make sure it actually takes 1-3 seconds and does not happen immediately. Otherwise, the SW has not really uploaded. If the DFU appears to upload immediately, check the "Choose" button you used or change the version of DfuSe SW to a different one
 - Disconnect the short circuit

- Start the Dashboard and press **RESET** button




- If you experience difficulties in DFU programming, please check and do the following:
 - Change your operation system (from Windows 10 to Windows 7 or vice versa)
 - Install a different DfuSe version (whichever works best with your Windows)


5.7 Setup the Dashboard SW

If you have uploaded the latest firmware for all of the boards, you can start to activate the system:

- While the beacon or modem is connected to the Dashboard, click the **DEFAULT** button on the Dashboard to upload the default settings




- Write down the beacon's address for future use or change the address at your convenience as shown [here](#)
- Press the **RESET** button on your beacons and modem after programming
- After programming devices with the latest software, the modem and beacons are ready for use
- Place the stationary beacons on the walls vertically in a way that will provide optimal ultrasonic coverage. It is recommended that you start with a simple 4m x6m room or so and place the stationary beacons on the opposite walls at a height of 1.85m (default). After familiarizing yourself with the system, more complex configurations can be made. The help video can be found [here](#)
- Connect the modem/router via USB to a Windows PC with the Dashboard installed
- Run the Dashboard. In the left corner of the Dashboard, the modem should be shown as connected
- Wake up all beacons by clicking on the buttons in the Dashboard on the panel
- It may take up to 7-10 seconds for the beacons to wake up




- Notice, that if the modem is not active and is not powered, the beacons will go into sleep mode automatically after 1 minute
- The system may run the frequency search, if it is the very first time you are waking up the beacons. If this step does not work, disconnect the modem and connect that beacon again via USB. Press the **DEFAULT** button in the Dashboard and the Read All button to make sure that the radio settings are really the default ones
- Compare the radio settings on the modem and the radio settings on the beacon. They must be the same

- Now you can check the height position of the beacons, RSSI, radio channel, threshold, etc. on the panel on the right corner of the Dashboard




read all		write all	
Hedgehog mode	disabled		
Supply voltage, V	3.70		
Height, m (-10.000..10.000)	1.850		
Time from reset, h:m:s	00:00:40 R		
Measured temperature, °C	39		
RSSI, dBm	-46		
Carrier frequency, MHz	433.400		
Device address (0..99)	23		
Channel	0		
Minimum threshold (-10..-2000)	-50		
Parameters of radio	(+ expand)		
Ultrasound	(+ expand)		
Interfaces	(+ expand)		
Misc. settings	(+ expand)		
Hedgehogs pairing	(+ expand)		

- It is possible to manage 255 beacons simultaneously. In current version one modem supports 255 beacons. If you do not see some of your connected beacons on the map, you may need to scroll to find their addresses
- Double click on the device both to put it into sleep mode and to wake it up
- The map will form and zoom in automatically
- [How to build map of DSP beacons](#)
- If the map does not form well, check the table of distances in the left corner of the Dashboard. The cells must be colored in white; it means the distances between stationary beacons are measured correctly



- If you see in the table some empty cells or marked **yellow/red**, it is an indication that distances between Some beacons are measured inconsistently or not measured at all. Try to re-position them because usually there is an obstruction of some sort in the between the beacons. It also may be different height of beacons' position. Reset all these beacons.

- Use **View => Table of distances** to monitor the measured distances between beacons




- Freeze the map by clicking the button. Stationary beacons will stop measuring relative distances and will be ready to measure distance from the mobile beacon(s)



- Turn on and wake up the mobile beacon following the same steps as with the stationary beacon: https://youtu.be/A4aRsH2-_E
- If you see on the devices' panel in the Dashboard that the beacon is colored **orange**, it means there are some differences in some of the settings between beacons. For example, some sensors may be off or some ultrasonic or radio settings may be different. You can change the settings for sensors manually by clicking on the panel on the upper right corner of the Dashboard to change the cells from gray to green to turn on sensor. It is recommended that the default settings on all beacons and the modem be used if this is your first time using the system
- After you freeze the map of stationary beacons, wake up the mobile beacon. After it wakes up, it will be traceable in 5-7 seconds
- The system is now fully operational

- In the dashboard, you can upload a picture / map of your room. You can use different picture for every floor. Go to [Loading the floorplan](#)




6. Setting up the system (Inverse Architecture)


6.1 How to launch Inverse system

If you want to use Inverse Architecture with DSP beacon, do the following steps:


- Flash modem and HW v4.9 beacons (They should have different frequencies e.g. 19KHz and 31KHz) (Check [HEX Programming](#) chapter)
- Download [Inverse SW](#)
- Open Dashboard SW
- Connect DSP beacon via USB.
- Wait until “Bootloader. Use “Firmware” menu” notification appears




- Click on “Firmware”



- Choose DSP IA software



- Click "Next" and wait for the download to complete



- Reconnect USB and wait for the beacon's appearance in the Dashboard
- Check the radio profile. It should be 500 Kbps

Parameters of radio	(-) collapse
Base frequency, MHz	918.999
Radio profile	500 Kbps


- Now, build the map, using [manual measurement](#)
- Add the service zone (Check [Submaps feature](#) chapter)
- Freeze the submap
- Wake up the hedgehog (DSP beacon)
- Freeze the map (If there is no tracking, try to refreeze it)
- If your tracking area is 2-6m, set manual amplifier to 17
- If your tracking area is 4-12m, set manual amplifier to 16
- If your tracking area is 8-20m, set manual amplifier to 15

Ultrasound	(-) collapse
Mode of work	Normal
High voltage TX settings	(+) expand
Analog power in sleep	enabled
Power after transmission	turn off
Transmitter mode	PWM
Frequency, Hz (100..65000)	12345
Duty, % (1..99)	55
Number of periods (1..100)	33
Amplifier limitation (calibrated)	4000
Amplification	manual
Receiver amplifier (0..4095)	17
Time gain control	disabled
Mode of threshold	automatic
Minimum threshold (-10..2000)	0
Threshold to noise, dB (3..100)	0
Signal detection	by ADC
Reset	Sleep
Wake up	Time sync
Zero IMU	Reset IMU
CTRL	Deep sleep
Default	

7. Dashboard menu and parameters

7.1 Dashboard general view

- This picture shows the Dashboard's general interface and items' positions



7.2 Table of distances

Table of distances shows measured distance between all the beacons. The map and its graphical visualization depends on distances. So, that is very important part of the system.

There are two ways of measuring:

- 1) Measuring by ultrasound (automatic)
- 2) Measuring by user (manual)

***Measuring by ultrasound is impossible for DSP beacons**

***In noisy cases and cases with a long distance it is better to use manual input**

- 1) Measuring by ultrasound:

- In most cases, the system builds the table of distances automatically. If everything is good, there would be figures in cells, they would be changing a little; cells color would be white

HIDE	5	22	66	77
5		7.144	12.389	10.101
22	7.144		10.122	12.151
66	12.389	10.122		6.879
77	10.101	12.151	6.879	

- If color differs, check the colors' definitions (next page) and solve the problem
- Freeze the map only if cells are white

- 2) Measuring by user (**necessary for DSP beacons and noisy cases**):

- Use manual input if table of distances didn't build. It may happen if environment is very noisy, or distances are very huge
- In that case, cells' color would be green
- Be careful with figures because a small mistake in that values will cause big mistakes in location

How to freeze/enter distance manually:

Step 1. Open the Dashboard. You will see the table of distances

Step 2. Use right mouse click on cell you want to freeze/enter. Additional menu will open. There you can control the table of distances. Choose **Freeze distance for pair** to freeze it

HIDE	5	22	66	77
5		7.144	12.389	10.101
22	7.144		10.122	12.151
66	12.389	10.122		6.879
77	10.101	12.151	6.879	

Freeze distance for pair

Freeze average for pair

Don't use distance

Freeze all

Unfreeze all

Enter distance for pair

Clear cell

Step 3. Now, cells are frozen. That values would not change until you unfreeze it. Even if beacons had been moved, distance would stay. Be careful with frozen cells because a small mistake can cause a huge impact on your tracking

HIDE	6	22	66	77
6		8.000	27.378	5.054
22	8.000		28.688	18.739
66	33.772	29.794		18.741
77	17.315	7.585	3.522	

Step 4. Repeat for all cells

HIDE	6	22	66	77
6		8.000	4.200	11.400
22	8.000		13.100	6.500
66	4.200	13.100		10.800
77	11.400	6.500	10.800	



- White means that everything is good, you can freeze the map



- Yellow means that something seems to be wrong, check distances and sensors before freezing



- Red means some critical misses, **DO NOT freeze the map**. Manually measure and enter distances



- Green means frozen distance, you can freeze the map, but be careful with values

7.3 Devices list

Devices list contains information about all the beacons in the system. It also allows to search, add and delete it.

<input type="checkbox"/> Device56	<input type="checkbox"/> Device57	<input type="checkbox"/> Device58	<input type="checkbox"/> Device59	<input type="checkbox"/> Device60	<input type="checkbox"/> Device61	<input type="checkbox"/> Device62	<input type="checkbox"/> Device63	<input type="checkbox"/> Device64	<input type="checkbox"/> Device65	<input type="checkbox"/> Device66	▲
<input type="checkbox"/> Device67	<input checked="" type="checkbox"/> Beacon68	<input type="checkbox"/> Device69	<input type="checkbox"/> Device70	<input checked="" type="checkbox"/> Beacon71	<input type="checkbox"/> Device72	<input type="checkbox"/> Device73	<input type="checkbox"/> Device74	<input type="checkbox"/> Device75	<input type="checkbox"/> Device76	<input type="checkbox"/> Device77	▼
Connected: COM3		X: 0.195, Y: -0.151						0		75 total, 0 failed (0%)	


Devices in this section are divided into two types:

- 1) Stationary beacon (beacon)
- 2) Mobile beacon (hedge)

- Devices list allows user to manage devices
- Use double click to send beacon asleep


- 1) Stationary beacon (beacon)

- Press right mouse button and additional menu will open
- There you can:
 - Remove beacon from current submap
 - Remove beacon from the whole network
 - Manually setup coordinates (x, y, z)



- 2) Mobile beacon (hedge)


- Press right mouse button and additional menu will open
- There you can:
 - Remove beacon from the network
 - Setup movement path
 - Upload zones (allowed and denied)
 - Manually setup coordinates (x, y, z)



7.4 Visualization settings

Visualization settings window has some functions to control visualization process:

- Clear map – clear all movement path
- Dots timeout – time of path's existence (Video: [Help: Dots timeout](#))
- Dots size mode – size of dots
- Save screenshot – files saves to **Dashboard's folder/screenshots**
- Freeze screen – The map freeze, no updates of the path




The image shows a vertical stack of controls for the visualization settings. At the top is a button labeled 'Clear map'. Below it is a label 'Dots timeout, sec' followed by a text input field containing the number '5' and a small up/down arrow button. Next is a label 'Dots size mode' followed by a dropdown menu showing 'default' with a downward arrow. Below that is a button labeled 'Save screenshot'. At the bottom is a button labeled 'Freeze screen'.

7.5 Map settings

Map settings helps to work with the map. Can do following things:

- Save map – saves map as *.ini* file into **Dashboard folder/maps**
- Load map – loads map from *.ini* format file
- Erase map – erases map and clears it



7.6 Modem/beacon's quick control panel

Control panel allows user to interact with devices. It can work with one device, or with all devices in the system.

List of functions:


Reset – Resets device

Sleep – Send device asleep (battery economy mode)

Wake up – Wakes up device (from sleeping mode)

Default – Drops all device's settings to factory default


Time sync – Sends time from your PC to hedgehog (for stream it out via UART)



Additional Ctrl feature:

To apply action to all beacons in the system, use **Ctrl + left mouse click** on button

Applicable only for buttons which turns **bold while Ctrl is pressed*



7.7 Modem's settings

This bar allows user to adjust devices very precisely. It contains a lot of parameters for advanced usage

Modem's settings

CPU ID	Copy to clipboard	143B43
Location update rate		16 Hz
Update rate speedup		none
Maximum speed, m/s (0.1..60.0)		5.0
Power save functions		disabled
Window of averaging (0..16)		4
Distance filter (0..16)		0
Advanced settings		(+) expand
High resolution mode (mm)		enabled
Accept new/woken devices		enabled
Inverse system		enabled
Distances only mode		disabled
Supply voltage, V		5.13
High voltage, V		n/a
Time from reset, h:m:s		00:01:09 R
Temperature of air, °C (-20..60)		23
RSSI, dBm		-69
Radio frequency band		915 MHz
Carrier frequency, MHz		919.000
Device address (0..99)		1
Channel		0
Parameters of radio		(+) expand
Interfaces		(+) expand
Georeferencing		(+) expand
Stationary beacons visible		enabled
Service zones visible		enabled
Service zones active		enabled

Unique processor ID for each device (beacon or modem)

Location update rate settings: 1/20Hz – 16Hz+. Notice that real update rate may be limited by distances between beacons or radio profile

TBD

Internal filter. More – faster objects can be tracked. Less – better filtering against location jumps

Set of power saving features. May not work in all settings or all SW releases. Keep disabled, if unsure

Averaging between location update measurements. More value – less location jitter, but higher latency

Filter of distances (as opposed to filter of locations). More – better filtering, but may be too conservative and "kill" good measurements

Keep Enabled normally. Switch to cm for backward compatibility

If map is frozen, new beacons will be accepted in the map, if enabled

TBD

CPU ID	Copy to clipboard	143B43
Location update rate		16 Hz
Update rate speedup		none
Maximum speed, m/s (0.1..60.0)		5.0
Power save functions		disabled
Window of averaging (0..16)		4
Distance filter (0..16)		0
Advanced settings		(+) expand
High resolution mode (mm)		enabled
Accept new/woken devices		enabled
Inverse system		enabled
Distances only mode		disabled
Supply voltage, V		5.13
High voltage, V		n/a
Time from reset, h:m:s		00:01:09 R
Temperature of air, °C (-20..60)		23
RSSI, dBm		-69
Radio frequency band		915 MHz
Carrier frequency, MHz		919.000
Device address (0..99)		1
Channel		0
Parameters of radio		(+) expand
Interfaces		(+) expand
Georeferencing		(+) expand
Stationary beacons visible		enabled
Service zones visible		enabled
Service zones active		enabled

TBD

Power supply voltage of the device 5V+-0.2V is OK

N/A

Time from the latest reset

Measured temperature of the processor's crystal

Strength of the radio signal from modem to beacons and vice versa. Maintain in the range of -25dBm to -80..-90dBm. Higher value - may overload. Lower – lost packets

Chosen working band

Exact working frequency

Logical address of the device. Keep 2..255 for beacons. Address

Pre-selected channel – one of the radio channels for communication between modem and beacons

If enabled, beacons will be seen as green dots on the map. If disabled, they won't be seen at all

Enable or disable visibility of Service Areas (Zones)

Make Service Zones active or not active

Advanced settings

Advanced settings	(-) collapse		TBD
Movement filtering	disabled		
Use pairs of beacons	disabled	Enabling will allow direction along with location:	
Analyze signal quality	enabled		
Minimum signal quality (0..100)	10		TBD
Track with low signal	blue		TBD

Parameters of radio

Parameters of radio	(-) collapse
Base frequency, MHz	919.000
Radio profile	38 Kbps
Device address (0..99)	77
Channel	1
Modulation	GFSK
Power of TX	9 dBm
Channel spacing, KHz (25.391..405.457)	49.190
Intermediate frequency (ID), KHz (0..787)	152
Offset frequency, KHz (-203.13..201.54)	76.16
Deviation frequency, KHz (1.587..380.859)	20.628
Channel bandwidth, KHz (58.036..812.500)	101.553
CCA mode	always
DC blocking filter	enabled
Manchester	disabled
Whitening	enabled
FEC	enabled

Real carrier frequency

Selected radio profile with a set of profile settings. Choose between 38kbps (better range and interference immunity, but slower); 153kbps – balanced; and 500kbps – the fastest, but the lowest radio range and least immune to interference

Logical address of the device. Distinguish of beacon from another

One of a predefined radio frequency channels

Modulation – a part of the radio profile. Only for advanced users

Only for advanced users

Only for advanced users

Only for advanced users

Parameters of radio	(-) collapse
Base frequency, MHz	919.000
Radio profile	38 Kbps
Device address (0..99)	77
Channel	1
Modulation	GFSK
Power of TX	9 dBm
Channel spacing, KHz (25.391..405.457)	49.190
Intermediate frequency (ID), KHz (0..787)	152
Offset frequency, KHz (-203.13..201.54)	76.16
Deviation frequency, KHz (1.587..380.859)	20.628
Channel bandwidth, KHz (58.036..812.500)	101.553
CCA mode	always
DC blocking filter	enabled
Manchester	disabled
Whitening	enabled
FEC	enabled

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Interfaces

Interfaces	(-) collapse	External UART interface settings
UART speed, bps	500000	
Protocol on UART/USB output	Marvelmind	

Different formats of data

Georeferencing

Georeferencing	(-) collapse
Latitude	N0.0000000
Longitude	E0.0000000

Geo-referencing for the (0,0,0) point on the map

Geo-referencing for the (0,0,0) point on the map

Beacon's settings

CPU ID	Copy to clipboard	172E42
Hedgehog mode		
Inverse system	enabled	
Distances only mode	disabled	
Supply voltage, V	3.96	
High voltage, V	n/a	
Height, m (-320.000..320.000)	0.000	
Time from reset, h:m:s	00:00:13 R	
Measured temperature, °C	39	
RSSI, dBm	-46	
Radio frequency band		
Carrier frequency, MHz	919.000	
Device address (0..99)	22	
Channel	0	
Minimum threshold (-10..-2000)		
IMU	(+) expand	
Parameters of radio	(+) expand	
Ultrasound	(+) expand	
Interfaces	(+) expand	
Misc. settings	(+) expand	
Hedgehogs pairing	(+) expand	

Unique CPU ID

Enable for mobile beacon and disable for stationary beacon

TBD

TBD

Measured voltage of internal battery

NA

Height – must be set for stationary beacons.
Must also be set for mobile beacons in 1D or 2D modes

Time from the latest reset

CPU ID	Copy to clipboard	172E42
Hedgehog mode		
Inverse system		enabled
Distances only mode		disabled
Supply voltage, V		3.96
High voltage, V		n/a
Height, m (-320.000..320.000)		0.000
Time from reset, h:m:s		00:00:13 R
Measured temperature, °C		39
RSSI, dBm		-46
Radio frequency band		
Carrier frequency, MHz		919.000
Device address (0..99)		22
Channel		0
Minimum threshold (-10..-2000)		
IMU		(+) expand
Parameters of radio		(+) expand
Ultrasound		(+) expand
Interfaces		(+) expand
Misc. settings		(+) expand
Hedgehogs pairing		(+) expand

Processor's crystal's temperature

Strength of the radio signal from this beacon to the modem, i.e. how the modem "hears" the beacon over radio. Keep below -25dBm and above -80..90dBm to avoid losses of packets. Lower end depends on radio profile and interference

Select radio frequency band according to your HW: 433MHz or 915MHz

Real carrier frequency

Selected device's address

Selected radio channel

TBD

IMU

IMU	(-) collapse	
Ax zero	-10	Calibration settings of embedded IMU: X shift
Ay zero	8	Calibration settings of embedded IMU: Y shift
Az zero	-122	Calibration settings of embedded IMU: Z shift
Ax K	0.982	Calibration settings of embedded IMU: X scale
Ay K	0.973	Calibration settings of embedded IMU: Y scale
Az K	0.982	Calibration settings of embedded IMU: Z scale

Parameters of radio

Parameters of radio	(-) collapse
Base frequency, MHz	919.000
Radio profile	38 Kbps
Device address (0..99)	77
Channel	1
Modulation	GFSK
Power of TX	9 dBm
Channel spacing, KHz (25.391..405.457)	49.190
Intermediate frequency (ID), KHz (0..787)	152
Offset frequency, KHz (-203.13..201.54)	76.16
Deviation frequency, KHz (1.587..380.859)	20.628
Channel bandwidth, KHz (58.036..812.500)	101.553
CCA mode	always
DC blocking filter	enabled
Manchester	disabled
Whitening	enabled
FEC	enabled

Real carrier frequency

Radio profile that is linked with many radio settings below. Helps to set them at once by choosing the profile. See similar in modem for more info

Device address – shall be set for each beacon different under one modem

One of the pre-selected frequency channels

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Parameters of radio	(-) collapse
Base frequency, MHz	919.000
Radio profile	38 Kbps
Device address (0..99)	77
Channel	1
Modulation	GFSK
Power of TX	9 dBm
Channel spacing, KHz (25.391..405.457)	49.190
Intermediate frequency (ID), KHz (0..787)	152
Offset frequency, KHz (-203.13..201.54)	76.16
Deviation frequency, KHz (1.587..380.859)	20.628
Channel bandwidth, KHz (58.036..812.500)	101.553
CCA mode	always
DC blocking filter	enabled
Manchester	disabled
Whitening	enabled
FEC	enabled

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Radio profile settings. No need to change manually. Only for advanced users

Ultrasound

Ultrasound	(-) collapse
Mode of work	TX+RX normal
High voltage TX settings	(+) expand
Analog power in sleep	disabled
Power after transmission	not turn off
Transmitter mode	PWM
Frequency, Hz (100..65000)	31000
Duty, % (1..99)	50
Number of periods (1..100)	5
Amplifier limitation (calibrated)	4000
Amplification	AGC
Time gain control	disabled
AGC desired level (-1800..0)	-500
AGC hysteresis (10..2000)	130
AGC step, dB (1..20)	3
Mode of threshold	automatic
Minimum threshold (-10..-2000)	-50
Threshold to noise, dB (3..100)	6
Signal detection	by ADC
Periods for detector (3..50)	5
Min. speed of raise, LSB/cm (0.5..127.0)	5.0
Min. over raise for new front (0..200)	10
Coef. of estimated front quality (0..200)	8
Maximum line gradient down, % (0..200)	0
Maximum triple deviation, % (0..250)	150
Maximum points to skip (0..5)	2

TX-RX – regular mode. Use it. The rest - internal

TBD

Power saving features. If not sure, keep default

Power saving features. If not sure, keep default

TBD

Frequency of ultrasonic pulses – set according to your HW

50% - default. 1% ... 99% lower strength of ultrasonic. Keep default

Number of ultrasonic pulses the TX beacon emits. More – stronger, but longer echo. For small distances – 1-10 periods. 20-30 – for 10-20 meters. For 20+ m – 50 periods

Internal settings

Automatic or manual gain control. Manual can be useful in special conditions: too high external audio noise, for example

Ultrasound	(-) collapse	TBD
Mode of work	TX+RX normal	
High voltage TX settings	(+) expand	AGC settings. For advanced users only
Analog power in sleep	disabled	
Power after transmission	not turn off	
Transmitter mode	PWM	AGC settings. For advanced users only
Frequency, Hz (100..65000)	31000	
Duty, % (1..99)	50	AGC settings. For advanced users only
Number of periods (1..100)	5	
Amplifier limitation (calibrated)	4000	
Amplification	AGC	AGC settings. For advanced users only
Time gain control	disabled	
AGC desired level (-1800..0)	-500	
AGC hysteresis (10..2000)	130	Deep ultrasonic trigger settings. For special cases only
AGC step, dB (1..20)	3	
Mode of threshold	automatic	
Minimum threshold (-10..-2000)	-50	Deep ultrasonic trigger settings. For special cases only
Threshold to noise, dB (3..100)	6	
Signal detection	by ADC	Keep ADC
Periods for detector (3..50)	5	
Min. speed of raise, LSB/cm (0.5..127.0)	5.0	
Min. over raise for new front (0..200)	10	Deep ultrasonic trigger settings. For special cases only
Coef. of estimated front quality (0..200)	8	
Maximum line gradient down, % (0..200)	0	
Maximum triple deviation, % (0..250)	150	
Maximum points to skip (0..5)	2	Deep ultrasonic trigger settings. For special cases only

Ultrasound	(-) collapse
Mode of work	TX+RX normal
High voltage TX settings	(+) expand
Analog power in sleep	disabled
Power after transmission	not turn off
Transmitter mode	PWM
Frequency, Hz (100..65000)	31000
Duty, % (1..99)	50
Number of periods (1..100)	5
Amplifier limitation (calibrated)	4000
Amplification	AGC
Time gain control	disabled
AGC desired level (-1800..0)	-500
AGC hysteresis (10..2000)	130
AGC step, dB (1..20)	3
Mode of threshold	automatic
Minimum threshold (-10..-2000)	-50
Threshold to noise, dB (3..100)	6
Signal detection	by ADC
Periods for detector (3..50)	5
Min. speed of raise, LSB/cm (0.5..127.0)	5.0
Min. over raise for new front (0..200)	10
Coef. of estimated front quality (0..200)	8
Maximum line gradient down, % (0..200)	0
Maximum triple deviation, % (0..250)	150
Maximum points to skip (0..5)	2

Deep ultrasonic trigger settings. For special cases only

Deep ultrasonic trigger settings. For special cases only

Deep ultrasonic trigger settings. For special cases only

Deep ultrasonic trigger settings. For special cases only

Deep ultrasonic trigger settings. For special cases only

			Deep AGC settings. For special cases only
			Deep AGC settings. For special cases only
			Deep AGC settings. For special cases only
			Deep AGC settings. For special cases only
AGC low threshold, raise speed (1..10)	15		
Speed of amplification increase (1..200)	10		
AGC high threshold, raise speed (1..100)	100		TBD
Speed of amplification decrease (1..200)	5		
Receive window low, m (0..255)	0		TBD
Receive window high, m (0..255)	255		
Minimum distance limitation	enabled		TBD
Auto measurements when radio gaps	enabled		
Filter selection	19 kHz		
RX1 normal	disabled		TBD
RX2 normal	disabled		
RX3 normal	disabled		TBD
RX4 normal	disabled		
RX5 normal	disabled		
RX1 frozen	disabled		Enable/disable sensor RX1 in map building mode
RX2 frozen	disabled		
RX3 frozen	disabled		
RX4 frozen	disabled		Enable/disable sensor RX2 in map building mode
RX5 frozen	disabled		
Additional parameters	(-) collapse		
Obstacles probe	disabled		
File of dump for DAC			

AGC low threshold, raise speed (1..10)	15	
Speed of amplification increase (1..200)	10	
AGC high threshold, raise speed (1..100)	100	
Speed of amplification decrease (1..200)	5	
Receive window low, m (0..255)	0	
Receive window high, m (0..255)	255	
Minimum distance limitation	enabled	
Auto measurements when radio gaps	enabled	
Filter selection	19 kHz	
RX1 normal	disabled	
RX2 normal	disabled	
RX3 normal	disabled	Enable/disable sensor RX3 in map building mode
RX4 normal	disabled	Enable/disable sensor RX4 in map building mode
RX5 normal	disabled	Enable/disable sensor RX5 in map building mode
RX1 frozen	disabled	Enable/disable sensor RX1 in map frozen/regular work mode
RX2 frozen	disabled	Enable/disable sensor RX2 in map frozen/regular work mode
RX3 frozen	disabled	Enable/disable sensor RX3 in map frozen/regular work mode
RX4 frozen	disabled	Enable/disable sensor RX4 in map frozen/regular work mode
RX5 frozen	disabled	Enable/disable sensor RX5 in map frozen/regular work mode
Additional parameters	(-) collapse	
Obstacles probe	disabled	Enable/disable sensor RX5 in map frozen/regular work mode
File of dump for DAC		TBD
		TBD
		TBD

Interfaces

Interfaces	(-) collapse	Speed of UART in hedgehog mode
UART speed, bps	500000	Type of protocol
Protocol on UART/USB output	Marvelmind	TBD
PA15 pin function	SPI slave CS	
Raw inertial sensors data	disabled	Enable or disable receiving raw IMU data with IMU update rate (100Hz)
Processed IMU data	disabled	Enable or disable receiving IMU+ultrasonic sensor fusion data with IMU update rate (100Hz)

Georeferencing

Georeferencing	(-) collapse	The same as with modem
Latitude	N0.0000000	
Longitude	E0.0000000	The same as with modem

Misc. settings

Misc. settings	(-) collapse	Timeout sleep settings
Sleep with external power	60 sec no connection	

Hedgehogs pairing

Hedgehogs pairing	(-) collapse
Pairing mode	no pairing

Enable for Paired Beacons feature:
<https://youtu.be/aBWUALT3WTQ>

7.8 CEILING and MIRRORING buttons on the Dashboard

- The **MIRRORING** button allows the map to be display as a mirror reflection
- The **CEILING** button shows where the mobile beacon is located with respect to the stationary beacons
- When the arrow points up, it means that the mobile beacon is below the stationary beacons
- When the arrow points down, it means that the mobile beacon is **above the stationary beacons**



7.9 Radio frequency band and Carrier frequency

- For beacons and modems 433 MHz allowable Radio bands 315 and 433,
- For beacons and modems 915 MHz allowable Radio bands 868 and 915, but when using antennas at 433 MHz it is possible to use both 315 and 433 MHz

*DSP beacons are 868/915MHz only

Radio frequency band	433 MHz
Carrier frequency, MHz	433.400

Radio frequency band	315 MHz
Carrier frequency, MHz	315.000

Radio frequency band	915 MHz
Carrier frequency, MHz	919.000

Radio frequency band	868 MHz
Carrier frequency, MHz	869.504

7.10 Different hedgehog colors in the Dashboard

You can choose any color for your hedge, but it still has some permanent colors, which inform you about some tracking issues:

- **Blue** - normal mode and confident tracking
- **Orange** - system provides the best location data possible, but confidence is lower, than blue
- **Colorless/transparent/blue** - usually, means lost radio packets
- **Colorless/transparent/orange** – usually, means weak ultrasonic coverage


8. SW feature/settings descriptions

8.1 Licenses


We added the licenses system. Now, you can order some additional features. It is not available in the basic Dashboard version, but you can easily purchase it if necessary. You can see the list on Marvelmind.com -> Products

To order:

- Go to Marvelmind.com -> Products
- Choose features which you want to get (e.g. [MMSW0001: 100Hz NMEA0183](#))




- Make an order
- Pay for the feature (via PayPal or other methods)
- Order the feature via the Dashboard by providing modem's CPU ID or send us email with the modem's CPU ID:
 - Open Dashboard SW
 - Connect modem to the Dashboard via USB
 - Go to **Licenses** → **View/activate licenses**



- Choose the licenses which you have purchased
- Press Order licenses

- Dashboard will generate a text




- Send generated text to info@marvelmind.com
- We will generate the license key and send to you via email
- Place the license key into Dashboard/Licenses folder:
 - Connect modem to the Dashboard via USB
 - Go to **Licenses** → **View/activate licenses**
 - Choose "Open license key"
 - Choose the license file (be careful if you have licenses for multiple devices, check CPU ID carefully)
- The features become activated in the Dashboard

8.2 Floors feature (FN0011)


The general view

Floor feature allows to build complicated multi-level maps. Every submap correspond some height, height corresponds to floors.




Floor's settings


- Every floor has its own adjustable height and its own floor plan




- Use right mouse button on the floor area to see an additional menu. There you can change floor's height. You can also insert your floorplan for that floor (.png, .jpeg, .bmp, .tiff)




Floor 4 and 5 are enabled:



Floor 5 is enabled:




Floor 4 is enabled:



Loading the floorplan

- **Right mouse button click on the floor -> Load floorplan -> Choose file** (.png, .jpeg, .bmp, .tiff).
- When the picture is loaded, you can drag the beacons to the points where they are actually located. After dragging two beacons, the picture with beacons will be combined in scale



8.3 Submap's settings

Every submap got its own settings. To correspond your submap to a certain floor, you need to adjust the height:

- To open that settings, use **left mouse button** on the **submap icon** -
- Change **Submap Z shift** value

Submap 0

Read all		Write all	
Starting beacon trilateration (0..255)	0		
Starting set of beacons	0; 0;0;0		
3D navigation	enabled		
Only for Z coordinate	disabled		
Limitation distances	manual		
Maximum distance, m (1..100)	30		
Submap X shift, m (-320.00..320.00)	0.00		
Submap Y shift, m (-320.00..320.00)	0.00		
Submap Z shift, m (-320.00..320.00)	16.00		
Submap rotation, degrees (-360.00..360.00)	0.00		
Plane rotation X, degrees (-360.00..360.00)	0.00		
Plane rotation Y, degrees (-360.00..360.00)	0.00		
Plane rotation Z, degrees (-360.00..360.00)	0.00		
Service zone thickness, m (-320.00..320.00)	0.00		
Hedges height in 2D mode, m (-320.00..320.00)	1.85		

Reset

Sleep

Wake up

Time sync

Zero IMU

☐ CTRL

Deep sleep

Default

Reset IMU

8.4 Axis rotation feature (FN0002)

General view

Axis extension allows user to rotate the map. There are the 90° gap between views.

It helps in case of multifloor tracking, when it is important to have a side view.

There are 3 directions of view:




- To change view, click on the icon

Example of views:


Y, X



X, Y






Z, X



8.5 Vertical submap feature (FN0003)

Vertical submap is a new feature for drone flights or some other specific cases. It gives user an opportunity to get a solid Z data for a vertical movement

Example: The drone flight



How to build vertical submap for stable Z:

- 1) For that configuration you need 6 stationary beacons

- 2) Place 4 beacons on the ground, facing each other. (make a square, where the edge points are beacons, looking in the center)
- 3) Place two beacons high on wall
- 4) Turn on RX4 only for beacons on the ground and RX4 and RX2 for beacons on the wall
- 5) Build the first submap (horizontal) consisting of all ground beacons
- 6) Change **Limitation distance** to **manual** and input the value in the submap's settings

Read all		Write all	
Starting beacon trilateration (0..255)	0		
Starting set of beacons	6; 7;0;0		
3D navigation	enabled		
Only for Z coordinate	disabled		
Limitation distances	manual		
Maximum distance, m (1..100)	12		
Submap X shift, m (-320.00..320.00)	0.00		
Submap Y shift, m (-320.00..320.00)	0.00		
Submap Z shift, m (-320.00..320.00)	0.00		
Submap rotation, degrees (-360.00..360.00)	0.00		
Plane rotation X, degrees (-360.00..360.00)	0.00		
Plane rotation Y, degrees (-360.00..360.00)	0.00		
Plane rotation Z, degrees (-360.00..360.00)	0.00		
Service zone thickness, m (-320.00..320.00)	0.00		
Hedges height in 2D mode, m (-320.00..320.00)	0.00		


- 7) Freeze and lock it



- 8) Build the second submap (vertical) horizontally consisting of two wall beacons and two ground beacons (neighboring with wall beacons)
- 9) Now, freeze it



- 10) Press axis rotation button
- 11) Click on the axis you want to rotate your submap along (when you point the cursor on the axis, it became visible and pink-colored)



- 12) Enter the corner value (90° usually)

Enter rotation angle

90.00

OK Cancel

- 13) Choose submap 2 and enable “Only for Z coordinates” mode

Read all Write all	
Starting beacon trilateration (0..255)	0
Starting set of beacons	0; 0;0;0
3D navigation	enabled
Only for Z coordinate	enabled
Limitation distances	manual
Maximum distance, m (1..100)	25
Submap X shift, m (-320.00..320.00)	0.00
Submap Y shift, m (-320.00..320.00)	0.00
Submap Z shift, m (-320.00..320.00)	0.00
Submap rotation, degrees (-360.00..360.00)	0.00
Plane rotation X, degrees (-360.00..360.00)	-88.24
Plane rotation Y, degrees (-360.00..360.00)	1.15
Plane rotation Z, degrees (-360.00..360.00)	-0.57
Service zone thickness, m (-320.00..320.00)	0.00
Hedges height in 2D mode, m (-320.00..320.00)	0.00

- 14) Change **Limitation distance** value

Read all Write all	
Starting beacon trilateration (0..255)	0
Starting set of beacons	6; 7;0;0
3D navigation	enabled
Only for Z coordinate	enabled
Limitation distances	manual
Maximum distance, m (1..100)	12
Submap X shift, m (-320.00..320.00)	0.00
Submap Y shift, m (-320.00..320.00)	0.00
Submap Z shift, m (-320.00..320.00)	0.00
Submap rotation, degrees (-360.00..360.00)	0.00
Plane rotation X, degrees (-360.00..360.00)	0.00
Plane rotation Y, degrees (-360.00..360.00)	0.00
Plane rotation Z, degrees (-360.00..360.00)	0.00
Service zone thickness, m (-320.00..320.00)	0.00
Hedges height in 2D mode, m (-320.00..320.00)	0.00


- 15) Change views and check the map
- 16) Wake up mobile beacon
- 17) Track

8.6 Handover zones setting


User must setup handover zones between submaps to guarantee handover quality for complex maps with multi-floor and similar

How to setup handover zones:

- Choose any submap



- Use **Alt + Left mouse click** on the other submap's service zone border(neighboring)
- Now, neighboring service zones are colored with green (dark green for chosen submap and light green for neighboring submaps)



8.7 Submaps feature (FN0004)

Submaps is a very powerful feature that allows building large maps (full business center, factory, warehouse with total area of 10,000...300,000 or more) based on smaller submaps (30...1000m²)


A submap is a part of the map. It includes a subset of used beacons covering part of the navigation area. Current version of Marvelmind system can include up to 10 submap. Please also check our [help video](#).

Follow these steps:

- Step 1. Choose the beacons which will be added to certain submap0...submapN
- Step 2. Connect the modem and put all the beacons into sleeping mode
- Step 3. Click "erase map" button for removing some current settings of beacons and submaps
- Step 4. Wake up all the beacons which should be served by submap0
- Step 5. Wait a little for map will automatically build. If needed use mirroring function
- Step 6. Freeze the submap
- Step 7. Add the new submap by clicking "+" button. New submap is automatically chosen as active
- Step 8. Wake up the beacons which should be served by submap1. By default, all the beacons are served by the last unfrozen submap
- Step 9. If the new submap should include beacons which are at the moment served by previous submaps (intersected submaps) click on each beacon, then right-mouse-click=>Add to current submap
- Step 10. If the new submap has 1 or 2 common beacons with previous submaps, it will settle as a part of the already built map. Two common beacons give a tight binding. If there is only one common beacon it's possible to drag and drop the submap. If submaps do not have common beacons it is needed to drag and drop the selected submap using the mouse and holding down the CTRL button. Rotation of submap can be executed by using the mouse wheel
- Step 11. Align submaps using M1/M2 parameter
- Step 12. Set Service Zones for each submap


Starting submaps

- Hedgehogs do not belong to any submap and can move between sub-map areas. Hedgehogs can be served not by only one submap at the same time. By default, the map consists of single sub-map, Submap0
- After adding new beacons to the system (waking them up), they appear in the first not frozen submap, or in the Submap0 if all the beacons are frozen
- Pressing the “+” button, add new empty submap to the system




- Press the button with the submap number (Submap0, Submap1 etc.) - select the corresponding submap
- In this state, if the modem button is pushed, the list of parameters on the right side represents some of the parameters of the selected submap, for example, “Starting beacon trilateration,” “Starting set of beacons,” etc.

- The system after adding beacons to the Submap0, adding new submap and the selection of Submap0




- Now we have 4 beacons, all in Submap0 (it can be seen near the table of distances)
- When the submap selected, the context menu of beacons buttons (available by right clicking the mouse) have the functions of adding and removing the beacons from the submap. In the picture above, we are removing beacon 3 from Submap0." Then we switch to Submap1 and add



this beacon to the submap


- When the submap selected, the beacons that do not belong to the submap are colored **gray**. In the same way, continue with removing beacon 10 from Submap0 and adding it to Submap1

- Now there are two beacons in Submap1, so this submap is built. "Submap 0" is built as well. Now we can freeze both submaps
- If pressing the "freeze map" button when the submap is selected, only the selected submap will be frozen. If pressing the "freeze map" button when the modem button is selected, all submaps will be frozen
- Now we have two good submaps, but they are not correctly located relative to each other. On the right side exist the parameters of shift and rotation for the selected submap; they can be filled in by hands. But a more user friendly way is to drag and drop the selected submap using the mouse and holding down the CTRL button.
- Rotation of submap can be executed by using the mouse wheel. The mirroring button also can be used; it affects only submaps that are selected




- After some movement, rotation, and mirroring of submaps, we can locate the submaps close to their real relative location
- Now the system is ready to use; we can wake up and track the mobile hedgehog
- In some cases the hedgehog can be lost between the submaps if this area is not covered by any of the submaps.

- Submaps can be removed from system using the context menu of the submap selection button (available with a right mouse click) M1/M2 parameter used for precise superposing submaps which do not have common beacons. So submaps cannot be aligned automatically



To align submaps:

1. Build the system like in previous instruction (1-11)
2. Put M2 in mode on by clicking the icon. Place the hedgehog near the boundary between two submaps. You will see 2 orange hedgehogs blinking, this is how the hedge is seen in two submaps
3. To align submaps correctly (CTRL + scroll/drag) against each other, until the orange mobile beacons are fully overlapped
4. Replace hedgehog to 1 or 2 points and repeat replacing submap for better superposing




Next step is to set service zones


Service zones are zones where the tracking is possible. If mobile beacon is out of the service zone it would not be tracking. If you built complicated map, you have to make service zones correctly. Service zones must be crossing in order to provide correct and glide tracking.

How to create a service zone:


- **Right mouse button on the submap icon -> Service zone**




- The service zone menu will open




- Use **SHIFT + Left mouse button** on the map to create point



- Use **SHIFT + Left mouse button** on the point to delete it



- Put points around submap, move them to provide service area for current submap. Service areas will cross each other. If hedgehogs get lost between two submaps expand the service area.




8.8 Paired beacons (FN0005)

- Two hedgehogs can be paired and work together as a single beacon without update rate reduction.
- Moreover, each beacon streams out in this mode not only its own location, but direction where the pair is facing. This feature hugely simplifies autonomous driving and flight. Here is updated [protocol](#) with the changes
- Please, also check our [help video](#).


Follow these steps:

1. Wake up stationary beacons and freeze the map
2. Wake up two hedgehogs which were pre-installed on robot/copter/drone
3. Choose one beacon and go to "Pairing mode" parameter and activate
4. Write the "Address of paired beacon", means number of the beacon, current selected hedgehog is paired with
5. Now choose location against center in parameters relatively the second beacon
6. Go to "Base of the pair" parameter and write actual distance between paired hedgehogs. Do the same for 2nd hedgehog.




8.9 Map settings

Save Map/Load Map feature and buttons are active now. You can build a very complex map with submaps and save all settings for the map, submaps, and all beacons including their ultrasonic gain, triggers, etc.




8.10 Hedge color change (FN0006)

If you have a lot of hedges, you can give everyone its own color to make them recognizable in the map




How to change hedgehog color:


- Right mouse button click on the hedge in the list of devices -> **Setup color**



- Choose any color which suits you and press **OK**




- Now, the hedgehog and its tracking path will be colored



8.11 Payload streaming (FN0007)

- Mobile beacon streaming user payload to modem. See the table with speed vs. payload



- All measurements were made with update rate setting 16 Hz. Real update rate is limited by distance, radio profile and payload data size.

8.12 IMU feature (FN0008)

- This function allows to increase data update rate received from ultrasound beacon with IMU due to sensor fusion up to 100 Hz, using inertial sensors (accelerometer, gyroscope)


Required:

- Starter set
- Hedgehog with IMU
- SW and firmware version 5.85 or newer
- Ultrasound Update rate 4Hz or higher

Setup IMU feature:


Accelerometer calibration

- Before you start use the feature check whether accelerometer has been calibrated
- Check if hedge was not calibrated before. Was damaged or fall down
- Put hedgehog on a flat surface (antenna directs up) and connect to your PC. Run the Dashboard



Go to **view => Accelerometer calibration** in open window click **autofill** and **clear table**.

After all values will refresh. Next, click **Pause (shift + space)**



Then take the beacon (hedgehog) and tilt it to each side towards the ground (like 6 times). rotate a little. You need to achieve x y z values:

- When antenna directs down $z \approx -1000$
=> antenna directs up $z \approx 1000$
- So, one of the axis values always will be - + 1000. Others ≤ 10 (preferably less 10, but 25 is also permissible)
- Every time before calibrating the hedgehog click **Pause**
- Accelerometer calibrator will choose the best value for each axe. At the end click **Calibrate** and close the window
- Calibration is needed to determine **g** value for each accelerometer axe

	X	Y	Z
Max	1013	1023	911
Min	-1008	-995	-1140
Delta	2021	2018	2051
Zero	2	14	-114
K	0.990	0.991	0.975
181	-44	39	-1126
180	-1	25	-1126
179	-9	18	-1125
178	-28	29	-1123
177	-21	33	-1124
176	44	139	-1114
175	9	40	-1131
174	-63	49	-1120
173	-45	146	-1112
172	-133	-14	-1121
171	-73	-65	-1131
170	-85	43	-1110
169	-67	38	-1120
168	-48	15	-1124

Start the system:

Setup the system as usual. It is described in paragraph [Setting up the system](#)

After the ultrasound tracking has started, select the hedgehog in the Dashboard, go to menu **Interfaces** (on the right) and enable **Processed IMU data**. After that, it is recommended to bring the hedgehog to real estate and press the ZERO IMU button (right-bottom) for additional sub-calibration of the gyro. After 5 seconds the hedgehog will begin streaming the processed IMU data.

Using Data in the Python Library Example:

Description of the protocol for streaming data: (link)

To work with data, you need to use some ready-made library, or develop your own software tools that can work with the described protocol.


Our company provides ready-made libraries for working with IMU in the following languages:

- python (link)
- c ++ (link)
- java (link)

An example with 3D imaging of a path on IMU with a frequency of 100Hz in real time, here: <https://marvelmind.com/pics/marvelmind-imu-tracker.zip>.

8.13 IMU axis positioning

HW v4.9 IMU axis positions



Mini-beacon IMU axis positions



IMU axis positions




DSP beacon

8.14 Player feature (FN0009)

This function is used to view the distance passed, the flight of the copter, etc. The player displays statistics on the maximum and average speed, the path traveled

1. Go to **File=>player**




2. This is how starting player menu looks like

Select log – opens save log file

Play – launch the player

RAW – if clicked, player shows raw data



Smooth – if clicked, player shows smooth data



- Now log is loaded. Important: for recording log file click **Save map** for saving all the beacons locations and attaching all the beacons to the log

At the top of the player you can see 5 dates:

- Top row from left to right: starting log, current playing, end of the log
- Bottom row: beginning of the limited area, end of the limited area
- Limited area distance between black triangles under slider. You can move triangles and zoom, place cursor on the slider + mouse wheel
- Triangles limit the area in which player works and the statistics is calculated



4. In play mode: **grey** points – RAW data, **blue** – Smooth

Choose the hedgehog will be displayed

In the main Dashboard window, you can turn off displaying service areas and stationary beacons by clicking **Service areas visible**, **Stationary beacons visible**



Statistics displayed depends on chosen hedgehog in the list

Max smooth forward, smooth backward – depth smoothing

Smooth threshold - smoothing ratio.




Service areas visible	enabled
Service areas active	enabled




8.15 Real-time player feature (FN0010)


Real-time player is a feature, which makes the tracking path smoother. As far as it looks backward and forward, it has some small delay



- Real-time player **turned on by default**




- You can turn it off if you need less delay



- You can tune it whether you need:
 - **Backward** – amount of dots which player 'looks' backward to provide smooth tracking
 - **Forward** – amount of dots which player 'looks' forward to provide smooth tracking

Tracking example:

Real-time player **turned off**



Real-time player turned on

File Language View Firmware Help

Marvelmind robotics

25 35 45 55 65 75

25	35	45	55	65	75
45	1.967	1.967	4.447	4.080	
55	4.447	3.864	3.864	4.951	
65	5.507	1.986	3.991	4.291	
75	4.080	4.951	3.236		

Clear map

Data timeout, sec: 50

Dot size mode: default

Save screenshot

Freeze screen

☒ Real-time Player

Backward Forward

5 3

modem V3.96.2 Jan

Submap 0

unfreeze map

Save map Load map

Erase map

device 1 device 2 device 3 device 4 device 5 device 6 device 7 device 8 device 9 device 10

device 11 device 12 device 13 device 14 device 15 device 16 device 17 device 18 device 19 device 20

Connected: COM3 X: 14.882, Y: -1.442 Rate: 6.0 Hz 1 708 total, 2 failed (0%)

Read all Write all

CPU ID Copy to clipboard 183328

Location update rate 16 Hz

Update rate speedup none

Maximum speed, m/s (0 1.60 3) 5.0

Power save functions disabled

Window of averaging (0 16) 0

Distance filter (0 16) 0

Advanced settings

High resolution mode (mm) enabled

Accept new/woken devices enabled

Inverse system disabled

Distances only mode disabled

Supply voltage, V 4.97

High voltage, V n/a

Time from reset, h:m:s 00:07:06 R

Temperature of air, °C (20.50) 23

RSSI, dBm -35

Radio frequency band 433 MHz

Carrier frequency, MHz 433.400

Device address (0 99) 1

Channel 0

Parameters of radio

Parameters of radio 10 expand

Hardware 10 expand

Georeferencing 10 expand

Stationary beacons visible enabled

Service zones visible enabled

Service zones active enabled

Активация Windows

Reset Sleep Wake up Time sync Zero map

CTRL Deep sleep Default Reset (M)

8.16 CSV format

Current Dashboard version supports additional timestamp. See the attached screenshot, the UNIX time in milliseconds is the first value

In each line comma separated values, CSV:

- UNIX time in milliseconds (time since 1970.01.01)
- time from previous record in milliseconds
- time from running dashboard in milliseconds
- address of hedgehog
- X coordinate of hedgehog, meters
- Y coordinate of hedgehog, meters
- Z coordinate of hedgehog, meters
- address of stationary beacon
- raw distance from hedgehog to stationary beacon, meters

The last pair (beacon address, distance) is repeated n times equal stationary beacons quantity in the system.

```
1494780417562,16,12287484,10,5.643,-0.553,0.453,12,6.343,13,3.169,14,9.814,15,5.841,
1494780417609,47,12287531,10,5.643,-0.553,0.453,12,6.343,13,3.169,14,9.814,15,5.841,
1494780417625,16,12287547,10,5.643,-0.552,0.466,12,6.343,13,3.169,14,9.814,15,5.841,
1494780417687,62,12287609,10,5.643,-0.552,0.466,12,6.343,13,3.169,14,9.814,15,5.841,
1494780417703,16,12287625,10,5.643,-0.552,0.466,12,6.343,13,3.169,14,9.814,15,5.841,
1494780417703,0,12287625,10,5.643,-0.552,0.466,12,6.343,13,3.169,14,9.814,15,5.841,
1494780417750,47,12287672,10,5.646,-0.550,0.466,12,6.343,13,3.169,14,9.814,15,5.841,
1494780417812,62,12287734,10,5.646,-0.550,0.466,12,6.343,13,3.171,14,9.811,15,5.840,
1494780417812,0,12287734,10,5.646,-0.550,0.466,12,6.343,13,3.171,14,9.811,15,5.840,
1494780417843,31,12287765,10,5.646,-0.550,0.466,12,6.343,13,3.171,14,9.811,15,5.840,
1494780417875,32,12287797,10,5.642,-0.553,0.466,12,6.343,13,3.171,14,9.811,15,5.840,
1494780417875,0,12287797,10,5.642,-0.553,0.466,12,6.343,13,3.171,14,9.811,15,5.840,
1494780417937,62,12287859,10,5.642,-0.553,0.466,12,6.347,13,3.172,14,9.813,15,5.837,
1494780417968,31,12287890,10,5.642,-0.553,0.466,12,6.347,13,3.172,14,9.813,15,5.837,
1494780418031,63,12287953,10,5.649,-0.551,0.466,12,6.338,13,3.171,14,9.813,15,5.843,
1494780418078,47,12288000,10,5.649,-0.551,0.466,12,6.338,13,3.171,14,9.813,15,5.843,
1494780418140,62,12288062,10,5.642,-0.553,0.466,12,6.338,13,3.171,14,9.813,15,5.843,
1494780418140,0,12288062,10,5.642,-0.553,0.466,12,6.338,13,3.171,14,9.813,15,5.843,
1494780418171,31,12288093,10,5.642,-0.553,0.466,12,6.463,13,3.169,14,9.813,15,5.837,
1494780418203,32,12288125,10,5.642,-0.553,0.466,12,6.463,13,3.169,14,9.813,15,5.837,
1494780418265,62,12288187,10,5.648,-0.551,0.459,12,6.463,13,3.169,14,9.813,15,5.837,
1494780418312,47,12288234,10,5.648,-0.551,0.459,12,6.345,13,3.172,14,9.813,15,5.844,
1494780418375,63,12288297,10,5.651,-0.549,0.459,12,6.345,13,3.172,14,9.813,15,5.844,
1494780418375,0,12288297,10,5.651,-0.549,0.459,12,6.345,13,3.172,14,9.813,15,5.844,
1494780418390,15,12288312,10,5.651,-0.549,0.459,12,6.346,13,3.171,14,9.812,15,5.846,
1494780418421,31,12288343,10,5.651,-0.549,0.459,12,6.346,13,3.171,14,9.812,15,5.846,
1494780418468,47,12288390,10,5.651,-0.549,0.459,12,6.346,13,3.171,14,9.812,15,5.846,
1494780418468,0,12288390,10,5.651,-0.549,0.459,12,6.346,13,3.171,14,9.812,15,5.846,
1494780418546,78,12288468,10,5.651,-0.552,0.459,12,6.346,13,3.175,14,9.812,15,5.846,
1494780418546,0,12288468,10,5.651,-0.552,0.459,12,6.346,13,3.175,14,9.812,15,5.846,
1494780418593,47,12288515,10,5.651,-0.552,0.459,12,6.346,13,3.175,14,9.812,15,5.846,
```

Unix time (time since 1970.01.01 in milliseconds)	Time from running dashboard (milliseconds)	Hedgehog N10 X= 5.651 m Y= -0.552 m Z= 0.459 m	Raw distances to stationary beacons: N12: 6.346 m N13: 3.175 m N14: 9.812 m N15: 5.846 m
Time from previous record, milliseconds			

9. Interfaces

Indoor “GPS” system supports many external interfaces that can feed measured location data to an external system (robot, copter, VR, etc.).

There are two different ways to obtain the mobile beacons’ location data from the system

1. From the mobile beacons
 - Each mobile beacon knows its own position and does not know the positions of the other mobile beacons
2. From modem/router
 - Knows position of every mobile beacon in the system

Data from the mobile beacons and from the modem can be obtained at the same time, if necessary

A list of the supported interfaces is shown below.


More information on the interfaces can be found here:

<http://marvelmind.com/#Interfaces>.


Supported interfaces

- | | | |
|--|---|---|
| <ul style="list-style-type: none">• Mobile beacon:<ul style="list-style-type: none">– UART– SPI– Virtual UART via USB– NMEA• Modem:<ul style="list-style-type: none">– UART– SPI– Virtual UART via USB | <ul style="list-style-type: none">• Integrated with:<ul style="list-style-type: none">– Windows (PC & tablets)– Linux– Mac OS– Android (beacon)– ROS (beacon)– Raspberry (beacon)– Arduino (beacon)– PixHawk (beacon) | <ul style="list-style-type: none">• Sample code:<ul style="list-style-type: none">– C– Python |
|--|---|---|

9.1 Beacon HW v4.9 external interface 4x4 pinout top view



9.2 Modem HW v4.9 external interface pinout top view



10. Advanced system settings and optimization

Start using advanced settings only when you know what you are doing

If you ran into troubles, connect the beacon or modem to the PC via USB and use the **DEFAULT** button. It will upload “factory settings” to the board while keeping the device address untracked.

Carrier frequency, MHz	433.400
Device address (0..99)	1
Channel	0
Parameters of radio	(+) expand
Interfaces	(+) expand
Georeferencing	(+) expand
Limitation distances	auto
Service areas visible	enabled
Service areas active	enabled
Submap X shift, m (-100.00..100.00)	0.00
Submap Y shift, m (-100.00..100.00)	0.00
Submap rotation, degrees (-360.00..360.00)	0.00

Активация Windows

Чтобы активировать Windows, перейдите в

sleepwake uptime sync

☐ CTRLdeep sleepdefault

10.1 How to place beacons

Avoid placing beacons on long sound-conducting objects

This is a very rare but may happen in some special circumstances.

The best practice is to place beacons (stationary and mobile) in places that would not result in the transfer of ultrasound energy from the beacon's board/case directly to the place it is attached via a medium other than air. For example, solid attachment of a beacon to a long horizontal metal tube may result in the following:

- Sound emitted from the beacon propagates directly to the metal tube
- Propagation losses inside metal are much smaller than in the air
Moreover, the tube may act as a low-loss waveguide
- If the tube is solid enough and long enough, there may be a weird effect where the receiving beacon receives the signal sooner than expected, i.e., sooner than the distance divided by the speed of sound in air. That happens because the speed of sound in metal is much higher than the speed of sound in the air. The ultrasound signal may even look stronger than the real signal propagated through the air due to the lower amount of losses of ultrasonic in metal than in the air
- It is good practice to place beacons on something relatively soft or something that does not conduct sound

Place beacons in a way that provides the proper ultrasonic coverage. It must be one beacon in the line of sight of minimum 2 beacons. Try to locate them under ceilings to avoid shadows, walls etc.

- Optimal settings for stationary beacons in small and big rooms
- Use 30–50 ultrasonic pulses for larger places and the default 5 pulses for smaller places
- Optimal settings for noisy environment

There are several ways to reduce impact:

- Mobile beacons can be placed very close to the source of noise without harm, but stationary beacons should be placed further from the noise because they are receiving the ultrasound, whereas the mobile beacon is emitting the ultrasound.

10.2 Using Oscilloscope


- Monitor ultrasonic signal from one beacon to another
- Use **Dashboard => View => Oscilloscope** to monitor ultrasonic signals from one beacon to another
- It is a very powerful tool, because it gives also information on the background noise, level of the signal, echo, etc. With this tool, it is easy to set up the proper ultrasonic threshold on the Dashboard.

Echo
External noises look similarly. Thus, choose the ultrasonic threshold below this value, for example, -500 to -2000

Type the reference beacon number. and press Enter

Ultrasonic signal front


Choose the beacon to test



10.3 Proper ultrasonic signal detection

When external noise is high:

- Identify the source. Usual suspects:
 - Ultrasonic-based volume or movement detection alarm systems
 - Other robots using ultrasonic
 - Parktronics
 - Sources of very strong white or impulse noise (air guns, air press, cutters, vacuum cleaner, etc.)
 - Rotors of drones/copters
- Marvelmind Indoor Navigation System uses proprietary 31kHz frequency for ultrasonic signal and employs additional filtering to combat external noise. This also makes the system rather immune against the “usual suspects.” However, if the external noise is too strong, its source is too close, or it’s emitting a strong signal on frequencies close to 31kHz or white noise, the system functionality can be affected.
- The best things to do in this case are to (1) identify the beacons that are affected. Usually, they are those that are the closest to the source of noise; (2) manually reduce the gain of the affected stationary beacons so that the signal from the mobile beacon would have a 1000–1800 amplitude. That would give the best signal-to-noise ratio. Don’t make the gain too high. The noise will be amplified, but the desired signal will be saturated and signal-to-noise ratio will be poor.
- The gain settings may be very non-linear. There is almost no change at 4000 to 3000. But around 2500, the gain starts reducing very quickly (1200 – for some HW versions). By setting the gain manually, it is possible to find the optimal gain to obtain the highest signal to noise ratio so the system can work even in very challenging external conditions.
- When the map is formed, only the mobile beacon is emitting, whereas stationary beacons are not. Thus, it does not matter how close the mobile beacon is to the source of the noise.
- But it matters how close the stationary beacons are to those sources. So select the positions of the stationary beacons accordingly - place them further from the sources of noise.



10.4 Using hedgehog.log file

- The system automatically records all measured positions in the hedgehog.log file that is stored in the same folder as the Dashboard.exe file
- The data is written in csv format; each line describes the position of one of the hedgehogs at a certain moment
- The line format is described [here](#).

10.5 System accuracy evaluation

1) Accuracy of distances measurement.

- Marvelmind navigation system can measure distances between beacons with accuracy of $\pm 2\text{cm}$ if it uses correct ultrasound speed in measurements
- The ultrasound speed depends of many factors: temperature of air, pressure, humidity and so on
- The main factor is temperature. In temperature range of $-20\dots+50\text{ }^{\circ}\text{C}$ the speed of ultrasound changes on about $0.6\text{ m/(s }^{\circ}\text{C)}$. It gives distance error about $(0.6 / 340) * 100\% \sim 0.17\% / ^{\circ}\text{C}$. So caused by incorrect temperature setting absolute error of distance measurement is 0.17% of real distance between beacons. For example, with distance 30 meters and $5\text{ }^{\circ}\text{C}$ error, this gives $0.85\% * 30 \sim 0.25\text{ meters'}$ error. Marvelmind system allows to setup temperature of air in the system settings


2) Accuracy of position measurement.

- Marvelmind system uses trilateration algorithm to calculate position by distances. The inaccuracy of position calculation is related to inaccuracy of distances measurement and to geometry of relative location of stationary and mobile beacons
- Basic trilateration formulas are given in this article:
<https://en.wikipedia.org/wiki/Trilateration>
- As you see, the position of mobile beacons **X**, **Y**, **Z** is calculated from positions of 3 stationary beacons which are set by values of **d**, **i**, **j**. One of the beacons was shifted to (0,0) position to simplify formulas in the article. In formulas for **X**, **Y** we see **d** and **j** in denominators. This means that with low values of **d** and **j** small error of this value can cause large position error
- Please see the picture of the beacons in the article - in more simple words, in means that if one of three beacons is close to line connecting other two beacons, it gives increased inaccuracy of locating mobile beacon
- For example:
 - assume $d=10, i=5, j=0.1, r_1=7, r_2=7, r_3=4.8$
 - We get $x=5, y=2.4375, z=4.25$
 - If we suppose that $j=0.101$ (0.1 cm error), we receive $x=5, y=-0.06, z=4.89$
 - You see very large Y error
- Another example for Z. Assume mobile beacon is relative close to plane of stationary beacons:
 - $d=8, i=4, j=6, r_1=5.02, r_2=5.02, r_3=3.01$
 - This gives $X=4, Y=3.01169, Z=0.36$
 - If we suppose $r_3=3.0$ (1 cm error), we receive $X=4, Y=3.016, Z=0.44$. Error on Z is about 8 cm
- Also, with $r_1=5, r_2=5, r_3=3, Z$ will be 0. As you see, low change of distances causes large change of Z value near the plane.

10.6 Calibration of the accelerometer

To calibrate an accelerometer on your beacon with IMU, you can do following steps:

- Connect the mobile beacon via USB to the Dashboard
- Make sure that the beacon has IMU on board: open **View / Accelerometer menu** and **view / gyro data**. In the presence of IMU graphics in these windows should display the angular velocity and acceleration when moving the mobile beacon (turn it in hands).
Close the window of the accelerometer and gyro data
- Open the calibration window: **View / calibrate the accelerometer**
- When calibrating, it measures the data of the free fall (gravity of the Earth) corresponding to each of the three axes X, Y, Z. The initial ones from these calculations remember the correction shifts indicated in the table as "Zero" and the correction factors indicated as "K"
- The switch at the right bottom of the window should be in the **AutoFill** position
- Before starting the calibration, click the **Reset** button at the top of the window - zeroing the current calibration results
- To calibrate: slowly, without jerking, manually turn the beacon in each of the 6 positions and keep it still for 1-2 seconds:
 - The starting position - the beacon lies on the table; the antenna is pointing upwards (calibration Z +)
 - The beacon is turned upside down, the antenna pointing down (calibration Z-)
 - The beacon is on the end, the sensor RX1 is pointing towards the table (calibration Y +)
 - The beacon rests on the end, the RX3 sensor points toward the table (calibration Y-)
 - The beacon rests on the end, the RX2 sensor is directed towards the table (calibration X +). In order not to interfere with the USB connector, the beacon can be placed on the edge of the table, so that the cable hangs down
 - The beacon rests on the end, the RX5 sensor points toward the table (calibration X-)
- In each measurement, the readings of the accelerometer are corrected by Zero and K.
At the end of the measurement of 6 points 7.1 ... 7.6, in the serviceable accelerometer Zero should be close to zero, and K close to 1, see the screenshot. If not - check if you forgot any of the points 7.1 ... 7.6.
- To save the results, click **Calibrate**.



Accelerometer calibration

	X	Y	Z
Max	1010	1018	988
Min	-1019	-988	-1089
Delta	2029	2006	2077
Zero	-4	15	-50
K	0.986	0.997	0.963
15	1008	11	-63
14	1009	11	-75
13	1003	21	17
12	-16	-987	-25
11	-16	-988	-16
10	-15	-987	-32
9	-8	1013	-64
8	-11	1018	-63
7	5	45	985
6	0	41	986
5	0	42	988
4	-2	44	979
3	0	57	977
2	0	39	986

Reset

Calibrate

Save

Load

Clear table

save line

pause

☐ manual fill
☒ auto fill


Number of averages: 20

Close

THIS PAGE INTENTIONALLY LEFT BLANK

10.8 Settings to obtain correct north direction

- In some cases, it is necessary to obtain a correct north orientation of the map for NMEA output from Marvelmind system. For example, when using a Marvelmind mobile beacon as the navigation data source for Pixhawk installed on a copter, correct north is required for correct yaw control of the copter. The Marvelmind system cannot determine north automatically, so the user should make corrections after building and freezing the map. It can be done in one of two ways:
 1. Rotate the Marvelmind map using the dashboard, as shown on the attached screenshot
 2. You can also view the video:
<https://www.youtube.com/watch?v=AsYXrtg7aVU&feature=youtu.be>
- Enter the angle correction (the angle shown on screenshot) on the Pixhawk side from the Mission Planner of APM Planner
- Refer to the parameter "BCN_ORIENT_YAW":
http://ardupilot.org/copter/docs/parameters.html?highlight=bcn_orient_yaw




- Beacons may issue raw sensor data. To learn how to obtain this data, please check this protocol:
https://marvelmind.com/pics/marvelmind_beacon_interfaces.pdf
- You can receive the data byte-by-byte and check for the required packet header
- See an example here:
http://www.marvelmind.com/downloads/2017_02_08_C_example.zip

10.9 Communication of Pixhawk with Marvelmind mobile beacon

The Marvelmind mobile beacon can be connected to Pixhawk (and to any other hardware or software that inputs GPS according to the NMEA0183 protocol). The mobile beacon can send GPS data via UART and USB (virtual UART) interfaces. For further explanation, please check out this [document](#).

10.10 Sending path to robot

1. The dashboard sends request to modem via USB.
Procedure of sending these requests in dashboard is shown on second screenshot.
This format of request is described in section 8 of modem protocol:
https://marvelmind.com/wp-content/uploads/2017/08/modem_usb_protocol_2017_01_27.pdf




2. Modem transmits data to the hedgehog via radio, using our proprietary protocol

- the hedgehog communicates with robot via UART. Hedgehog sends data according to section 2.3.1 of this protocol:

https://www.marvelmind.com/pics/marvelmind_beacon_interfaces_v2017_09_13.pdf

The robot should confirm receiving data by response packet shown in section 2.3

This communication on the robot side is implemented in the Arduino example on our site. As you can see in the protocol, robot should not request the waypoints, the hedgehog will send the waypoints when they will be transmitted from dashboard. But robot should confirm receiving each waypoint by this packet:
[0x03,0x47,0x01,0x02,0x00, <2 bytes of checksum>]



10.11 Proper ultrasonic coverage

The single most important requirement for the system to work well is to have proper ultrasonic coverage

Each sensor has an ultrasonic beam of ~90 degrees. Outside of that range, the emitting power and sensitivity drops quite rapidly. From the left, right, or back of the ultrasonic sensor, the signal is highly attenuated. Thus, it is crucial to provide proper ultrasonic coverage for the area where the robot will be moving.

- It is also very important to provide proper ultrasonic coverage to the stationary beacons when the map is being formed
- **Mobile beacon (“hedgehog” or “hedge”) is designed to be placed horizontally**
- The mobile beacon has four horizontal and one vertical sensor, each covering its own sector. Together, they cover 360 degrees horizontally and 180 degrees in the upper hemisphere. The lower hemisphere is highly attenuated, so don't expect ultrasonic coverage in that area
- It is advised that the mobile beacon be placed as high as possible on the robot if the stationary beacons are above the mobile beacon. This minimizes shadows from other objects, people, etc.

The screenshot displays the Marvelmind robotics management interface. The main window shows a 2D map with a grid overlay. A table in the top-left corner lists sensor data for beacons 22 through 26. The table has columns for sensor ID, X, Y, Z coordinates, and a status column. The status column shows 'RX normal' for beacons 22, 23, 24, and 25, and 'RX frozen' for beacon 26. The map itself shows several beacons represented by colored dots with their coordinates. A compass rose is visible in the bottom-left corner. On the right side, there is a configuration panel with various settings for the Hedgehog mode, including supply voltage, height, temperature, RSSI, and radio parameters. At the bottom, there is a list of devices (beacons and devices) with checkboxes for selection. The interface also includes buttons for 'clear map', 'save screenshot', 'freeze screen', 'unfreeze map', 'save map', 'load map', and 'erase map'.

22	23	24	25	26
10.262	10.262	10.398	6.618	
10.262	9.993	4.853		
10.398	9.993	11.345		
6.618	4.853	11.345		
6.991	3.699	9.947	2.003	

- Example of proper positioning of the mobile beacon can be found here:
<https://youtu.be/PFgNPkLGCDk>
- The beacon is placed horizontally and above other objects that can cast a shadow on the stationary beacons
- **Keep the radio signal's strength under control**
- The RSSI (Dashboard => right menu) of any beacon/modem must not be higher than -25dBm. Otherwise, the system may malfunction

It is recommended the distance between the modem and beacons be no less than 0.5–1m. Beacons can be placed as close to each other as needed. If a beacon is extremely close to the modem, disconnect the antenna from the beacon. Monitor the Received Signal Strength Indicator (RSSI). It must be in the range of -25 to -70dBm. An RSSI of less than -70dBm will work too, but packet losses may start occurring. The quality of the radio connection very much depends on external interference as well because the used band is ISM (either 915MHz or 433MHz) and there are numerous co-existing systems.

Use 30 - 50 periods (pulses) in settings instead of the default 5. Select:


Ultrasound settings => Number of periods

Ultrasound	(-) collapse
Mode of work	TX+RX normal
Analog power in sleep	enabled
Power after transmission	not turn off
Frequency, Hz (100..65000)	31000
Duty, % (1..99)	50
Number of periods (1..100)	5
Amplifier limitation (calibrated)	4000
Amplification	AGC
AGC desired level (-1800..0)	-500
AGC hysteresis (10..2000)	130
AGC step, dB (1..20)	3
Mode of threshold	automatic
Minimum threshold (-10..-2000)	-50

When you have large errors in position estimation (more than a 1m inaccuracy), use the embedded Oscilloscope on **Dashboard => View** to determine which stationary beacon is jammed

Reduce the gain of the ultrasonic manually depending on your system

10.12 Sensors settings: example for 2D and mobile beacon



Beacon 2

RX1 and RX4 emit ultrasound in normal mode for better ultrasonic signal exchange with Beacon 3. In frozen mode RX2 added as working sensor. The rest sensors are turned off

Changing sensors' settings could be found in the panel in the upper right corner of the Dashboard during your beacon is connected to the computer

Beacon 3

RX3 and RX4 emit ultrasound in normal mode for better ultrasonic signal exchange with Beacon 2. In frozen mode RX2 added as working sensor. The rest sensors are turned off

10.13 Powering beacons

Depending on the type of beacon, may be internal battery, or external USB power supply, for more details check [comparison table](#)

Battery lifetime totally depends on the mode of operation and can be varied between several days to several months (or more for special applications)

11. Frequently Asked Questions

Please check this [forum](#) for more information. Here we will answer the most common questions

1 What is the proper way to place the beacons?

- The actual distance between beacons must be ≤ 30 m. Provide the line of sight from one beacon to minimum two others

2 How far can beacons be located from modem?

- In the open space the distance from the modem to the beacon can reach several hundred meters

3 What if hedgehog shown as **orange** circle or **transparent** inside in the Dashboard?

- **Blue** - normal mode and confident tracking
- **Orange** - system provides the best location data possible, but confidence is lower, than blue
- **Colorless / transparent** - usually, means lost radio packets or no ultrasound coverage

4 What is the obstacle for ultrasound?

- The real obstacles for ultrasound are walls (concrete), glass, metal. If you need to cover a multiple-floor territory you can use our Submap feature in which case the tracking will not be interrupted

5 How the system works in very low and very high temperatures?

- System is designed for normal office-like conditions and temperatures 0 °C - 40 °C
- You can see some other types of beacon (outdoor, explosion safe, etc.) in the [comparison table](#)
- We also possible to produce some special versions, which will suit your case. Please write to info@marvelmind.com

6 Are beacons resistant to explosions, dust, dirt, water, noise?

- Low-frequency noise (motor noise, industrial equipment) does not interfere with the normal operation of the system
- You can see some other types of beacon (outdoor, explosion safe, etc.) in the [comparison table](#)

7 What is the time of delay between positioning the object and respond?

- The delay is directly proportional to the update rate. For example, if update rate is 16 Hz delay is 1.2:1.5x60ms
- The limit is 1.5x times the maximum distance between the stationary beacons. To expand the service area, please follow the instructions shown in the attached screenshot. Notice that positioning the mobile

beacon far from stationary beacons and close to their plane may result in increased positioning error because of bad geometry of measurement

8 How to define IMU or not IMU beacon?

- Check white sticker on the box and on the beacon's bottom /IMU - with IMU
- Connect beacon via USB: Dashboard => View => Accelerometer data

9 Can we use none-IMU beacon as mobile beacon or not?

- Yes, you can (https://www.youtube.com/watch?v=A4aRsjH2-_E)


10 What is the reason to choose 915Mhz vs 433Mhz?

- The 915MHz version is designed for the US, Canada and Americas in general. The ISM band (license-free band for industrial, science and medical applications) in those countries is 915MHz
- In Europe, it is 433MHz

12. Troubleshooting check-list


If you have any problems with the system, follow this simple steps:

- **Update SW** on modem and beacons



- Now, connect all beacons and modem one by one and press **Default** button in the Dashboard (When updating the SW, please, press **Default** button to make sure that beacons really have default settings. Otherwise, modem may be calling on a wrong channel or something)

- Press **Erase map**



Check-list before starting the system:

- Keep modem 1-2m away from beacons. if closer, the beacons radio may be overloaded
- Be sure that you use SW from the same pack
- When updating the SW, please, press Default button to make sure that beacons really have default settings. Otherwise, modem may be calling on a wrong channel or something
- Start with simple configuration (10x10m square, 4 stationary beacons)
- Do not obstruct line of sight between beacons
- Build the map first, freeze it, then wake up the “hedge”
- Number of periods. By default – 5; For longer distances, you shall put it 10-50

13. Contacts

For additional support, please send your questions to info@marvelmind.com